

Date: Monday, 6/5/2006 11:26:24 AM
User: Kim Johnston

Process Sheet

Customer	: CU-DAR001 Dart Helicopters Services	Drawing Name	: 0H-58 SKIDTUBE ASSEMBLY
Job Number	: 27397		
Estimate Number	: 10475		
P.O. Number	: N/A	Part Number	: D058672041
This Issue	: 6/5/2006	S.O. No.	: N/A
Prsht Rev.	: NC	Drawing Number	: D2922 REV A1
First Issue	: 6/5/2006	Project Number	: N/A
Previous Run	: 27392A	Drawing Revision	: A1
		Material	: N/A
Written By	: <i>See Comment Below</i>	Due Date	: 6/30/2006
Checked & Approved By	: <i>06.06.05 n</i>	Qty:	1 Um: Each
Comment	: Est Rev: 06.02.06 Re-format; ECN 258 KJ Est Rev: D 06.02.06 Added Dt8025 EC		

Additional Product

Job Number:



Seq. #:	Machine Or Operation:	Description :
---------	-----------------------	---------------

1.0	DC	DOCUMENT CONTROL
-----	----	------------------



Comment: DOCUMENT CONTROL

Photocopy bluefile & type labels per PPP D058-672-041 CHG001

KS 06.06.19

2.0	D2620	Bent 206 Skidtube
-----	-------	-------------------



Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s)

Pick:

Qty Part Number Description

Batch

1 D2620

Bent Tube 3" OD

B27205
BE 06-06-15

3.0	LANDING GEAR 1	LANDING GEAR RESOURCE 1
-----	----------------	-------------------------



Comment: LANDING GEAR RESOURCE 1

1-Deburr Fwd edge of tube

BE 06-06-15

2-Cut aft end of D2620 bent tube as per dwg D2922

BE 06-06-15

3-Drill pilot holes using drill jig DT8480 and DT8025 open to 0.312" dia.

BE 06-06-15

4-Drill holes for wearplates using DT 8487 Open to 0.297" dia.

BE 06-06-15

5-Drill holes for aft cap as per Dwg D2922 using drill jig DT 8025. Open using #6 Drill Bit

BE 06-06-16

7-Remove inner indexing ridge on aft end of skidtube as per Dwg D2922

BE 06-06-16

8-Deburr and Blow out all chips form inside the tube

BE 06-06-16

9-Weld D2794 cap as per QSI 004 and Dwg D2922. Use aluminum rod.

BE 06-06-16

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Mfg / Design Mgr	Approval QC Inspector

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Design Mgr	Approval QC Inspector
			Initial Design Mgr	Action Description Design Mgr	Sign & Date			

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

NOTE: Date & initial all entries

QA: N/C Closed: _____ Date: _____

Date: Monday, 6/5/2006 11:26:24 AM
User: Kim Johnston

Process Sheet

Customer: CU-DAR001 Dart Helicopters Services

Drawing Name: 0H-58 SKIDTUBE ASSEMBLY

Job Number: 27397

Part Number: D058672041

Job Number:



Seq. #:

Machine Or Operation:

Description :

A/R Aluminum Rod

m18839/m100660 RT 06-06-16

4.0

HAND FINISHING1

HAND FINISHING RESOURCE #1



Comment: HAND FINISHING RESOURCE #1

Chemical Conversion Coat as per QSI 005 4.1

RT 06-06-20

5.0

D2923

Web



Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s)

Pick:

Qty Part Number Description Batch

1 D2923 Web

327421 RT 06-06-20

6.0

LANDING GEAR 1

LANDING GEAR RESOURCE 1



Comment: LANDING GEAR RESOURCE 1

1-Open holes to finished size as per Dwg D2922(without cutting fluid)

RT 06-06-20

2-Countersink crossbolt spacer holes as per Dwg D2922(without cutting fluid)

RT 06-06-20

3-Deburr and Blow out all chips from inside the tube

RT 06-06-20

4-Bond D2923 web in place as per QSI 015. Ensure holes lineup

A/R Sikaflex-291

M101126

Sikaflex expire date: *06-11-01*

RT 06-06-20

7.0

QC5

INSPECT WORK TO CURRENT STEP



Comment: INSPECT WORK TO CURRENT STEP

DP 06-6-21

8.0

D2794

Cap



Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s)

Qty

Part Number Description

1 D2794

Fwd Cap

Batch

3 14400

RT 06-06-16

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Mfg / Design Mgr	Approval QC Inspector

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Design Mgr	Approval QC Inspector
			Initial Design Mgr	Action Description Design Mgr	Sign & Date			

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

NOTE: Date & initial all entries

QA: N/C Closed: _____ Date: _____

Date: Monday, 6/5/2006 11:26:24 AM
User: Kim Johnston

Process Sheet

Customer: CU-DAR001 Dart Helicopters Services

Drawing Name: 0H-58 SKIDTUBE ASSEMBLY

Job Number: 27397

Part Number: D058672041

Job Number:



Seq. #:

Machine Or Operation:

Description :

9.0

D2649

Crossbolt Spacer



Comment: Qty.: 22.0000 Each(s)/Unit Total: 22.0000 Each(s)

Pick:

Qty Part Number Description Batch

22 D2649

Crossbolt spacer

B25864 BE 06-06-22

10.0

LANDING GEAR 1

LANDING GEAR RESOURCE 1



Comment: LANDING GEAR RESOURCE 1

1-Weld D2649 cross bolt spacers as per QSI 004 and Dwg D2922.(Remember to back drill each hole to 0.250" before welding the other side)

A/R Aluminum Rod

M18839 BE 06-06-22

3-Grind welds flush as per Dwg D2922

DP 06-6-27

4-Counterbore 5/16" x 0.750" deep as per Dwg D2922

BE 06-06-27

11.0

QC5/9

WELD INSPECTION



QC9 > PD 06-06-27(1)

Comment: WELD INSPECTION

Job 06-28(1)

12.0

POWDER COATING

POWDER COATING



Comment: POWDER COATING

Powder Coat White Gloss (Ref: 4.3.5.1) as per QSI 005 4.3

DC SC 06/07/06

13.0

QC3

INSPECT POWDER COAT/CHEMICAL CONVERSION



Comment: INSPECT POWDER COAT/CHEMICAL CONVERSION

a.m 06-07-06 (1)

14.0

D26483

Wearpad



Comment: Qty.: 5.0000 Each(s)/Unit Total: 5.0000 Each(s)

Pick:

Qty Part Number Description Batch

5 D2648-3

Wearpad

B25904

a.m 06-07-06 (1)

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Mfg / Design Mgr	Approval QC Inspector

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Design Mgr	Approval QC Inspector
			Initial Design Mgr	Action Description Design Mgr	Sign & Date			

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

NOTE: Date & initial all entries

QA: N/C Closed: _____ Date: _____

Date: Monday, 6/5/2006 11:26:24 AM
User: Kim Johnston

Process Sheet

Customer: CU-DAR001 Dart Helicopters Services

Drawing Name: OH-58 SKIDTUBE ASSEMBLY

Job Number: 27397

Part Number: D058672041

Job Number:



Seq. #:

Machine Or Operation:

Description :

15.0

D265615

Wearplate



Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s)

Pick:

Qty Part Number Description Batch

1 D2656-15 Wearshoe B2Y845

16.0

D265621

Wearplate



Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s)

Pick:

Qty Part Number Description Batch

1 D2656-21 Wearshoe B20917

17.0

D2924

Wearshoe



Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s)

Pick:

Qty Part Number Description Batch

1 D2924 Wearshoe B22595

18.0

MS27039108

Screw



Comment: Qty.: 50.0000 Each(s)/Unit Total: 50.0000 Each(s)

Pick:

Qty Part Number Description Batch

50 MS27039-1-08 Screw m19551

19.0

AN960JD10L

Washer



Comment: Qty.: 50.0000 Each(s)/Unit Total: 50.0000 Each(s)

Pick:

Qty Part Number Description Batch

50 AN960JD10L Washer m18235

85
140
m10291

g.m 06-07-06

(1)

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Mfg / Design Mgr	Approval QC Inspector

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Design Mgr	Approval QC Inspector
			Initial Design Mgr	Action Description Design Mgr	Sign & Date			

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

NOTE: Date & initial all entries

QA: N/C Closed: _____ Date: _____

Date: Monday, 6/5/2006 11:26:24 AM
User: Kim Johnston

Process Sheet

Customer: CU-DAR001 Dart Helicopters Services

Drawing Name: 0H-58 SKIDTUBE ASSEMBLY

Job Number: 27397

Part Number: D058672041

Job Number:



Seq. #:

Machine Or Operation:

Description :

20.0

ALS41032130

Insert



Comment: Qty.: 5.0000 Each(s)/Unit Total : 5.0000 Each(s)

Pick:

Qty Part Number Description Batch

50 ALS4-1032-130 Insert

m18293

or (see QSI 017)

21.0

D26511

Plug



Comment: Qty.: 20.0000 Each(s)/Unit Total : 20.0000 Each(s)

Pick:

Qty Part Number Description Batch

20 D2651-1 Plugs

D25144

22.0

D26513

O-Ring



Comment: Qty.: 20.0000 Each(s)/Unit Total : 20.0000 Each(s)

Pick:

Qty Part Number Description Batch

20 D2651-3 O-Rings

D23491

23.0

D2646

Aft Cap



Comment: Qty.: 1.0000 Each(s)/Unit Total : 1.0000 Each(s)

Pick:

Qty Part Number Description Batch

1 D2646 Aft Cap

B25381

24.0

MS27039108

Screw



Comment: Qty.: 2.0000 Each(s)/Unit Total : 2.0000 Each(s)

Pick:

Qty Part Number Description Batch

2 MS27039-1-08 Screw

m19551

A.M 06-02-06 (1)

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Mfg / Design Mgr	Approval QC Inspector

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Design Mgr	Approval QC Inspector
			Initial Design Mgr	Action Description Design Mgr	Sign & Date			

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes ☒ No ☐ DQA: ☒ ☐ Date: 06/07/10

NOTE: Date & initial all entries

QA: N/C Closed: _____ Date: _____

Date: Monday, 6/5/2006 11:26:25 AM
User: Kim Johnston

Process Sheet

Customer: CU-DAR001 Dart Helicopters Services

Drawing Name: 0H-58 SKIDTUBE ASSEMBLY

Job Number: 27397

Part Number: D058672041

Job Number:



Seq. #:

Machine Or Operation:

Description :

25.0

AN960JD10L

Washer



Comment: Qty.: 2.0000 Each(s)/Unit Total: 2.0000 Each(s)

Pick:

Qty Part Number Description Batch
2 AN960JD10L Washer

m101291

~~04-13-05~~

a.m 06-07-06 (1)

26.0

HAND FINISHING1

HAND FINISHING RESOURCE #1



Comment: HAND FINISHING RESOURCE #1

1-Install inserts & wearpads as per dwg D2922. Insert a drop of Sikaflex at insert hole before installing wearplates.

A/R Sikaflex-291

m101193

Sikaflex expire date: *06-11-06*

2-Install O-Rings D2651-3 on plugs D2651-1 with Petroleum Jelly and install plugs as per Dwg D2922

3-Install D2646 Aft Cap and seal with Sikaflex adhesive. Clean excess adhesive

A/R Sikaflex-291

m101193

Sikaflex expire date: *06-11-06*

a.m 06-07-06 (1)

3- Wing Walk as per Dwg D2922 and QSI 005 4.4

m101266

Batch:

FL 06/07/06 (1)

27.0

QC3/5

INSPECT WORK/WING WALK



Comment: INSPECT WORK/WING WALK

DL 06/07/07 (1)

28.0

PACKAGING 1

PACKAGING RESOURCE #1



Comment: PACKAGING RESOURCE #1

Identify and Stock

Location:

Rec C

06/7/11 (1)

29.0

DC

DOCUMENT CONTROL



Comment: DOCUMENT CONTROL

Inspection Level 21

06/07/12 (1)
06/07/11

Job Completion



W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Mfg / Design Mgr	Approval QC Inspector

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Design Mgr	Approval QC Inspector
			Initial Design Mgr	Action Description Design Mgr	Sign & Date			

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

NOTE: Date & initial all entries

QA: N/C Closed: _____ Date: _____

DART

DESIGN RF	DRAWN BY RF	DART AEROSPACE USA, INC. BELLEVUE, WA	
CHECKED [Signature]	APPROVED [Signature]	DRAWING NO. D2922	REV. A SHEET 1 OF 2
DATE 99.10.14		TITLE OH-58 SKIDTUBE ASSEMBLY	SCALE NTS
A	99.10.14	NEW ISSUE	
A1	# CP 01.08.20	Ø0.640 WAS Ø0.625	

RELEASED
00.05.11 #

Qty	Part Number	Description
X	D2922-041	SKIDTUBE ASSEMBLY
*	D2600-1	EXTRUSION
1	D2646	AFT CAP
4	D2648-3	WEARPAD
1	D2648-5	WEARPAD
22	D2649	CROSS BOLT SPACER
20	D2651-1	PLUG
20	D2651-3	O-RING
1	D2656-15	WEARSHOE
1	D2656-21	WEARSHOE
1	D2794	CAP
1	D2923	WEB
1	D2924	WEARSHOE
50	AKS7-1032-130 or AKS4-1032-130 or ALS7-1032-130 or ALS4-1032-130	INSERT
52	AN960JD10L	WASHER
52	MS27039-1-08	SCREW

GENERAL NOTES:

- 1) TOLERANCES ARE PER DART QSI 018 UNLESS OTHERWISE NOTED
- 2) LENGTH OF D2600-1 EXTRUSION REQUIRED BEFORE BENDING = 160 INCHES.*
- 3) INSERT D2923 WEB TO LOCATION SHOWN OFF AFT END OF SKIDTUBE AND BOND WEB INTO OUTER TUBE WITH NON-STRUCTURAL SIKAFLEX-241/291 ADHESIVE PER DART QSI 015 AFTER BENDING.
- 4) USE DART DRILL TEMPLATE DT8406 TO LOCATE AND DRILL Ø0.297 HOLES FOR WEARSHOE INSERTS. INSTALL AKS7-1032-130 PER SECTION D-D (50 PLACES) AFTER FINISH. INSTALL MS27039-1-08 SCREWS AND AN960JD10L WASHERS IN ALL INSERTS. SEAL WITH SIKAFLEX-241/291.
- 5) WELDING TO BE DONE PER DART QSI 004.
- 6) FINISH:
ACID ETCH, ALODINE PER DART QSI 005 4.1 PRIOR TO INSERTING D2923 WEB
POWDER COAT ASSEMBLY GLOSS WHITE (REF 4.3.5.1) PER DART QSI 005 4.3
BLACK ANTI-SKID PAINT AS INDICATED TO 0.50 ABOVE LOCATION RIDGE PER DART QSI 005 4.4
- 7) INSERT D2651-1 PLUG C/W D2651-3 O-RING IN HOLES MARKED 'P' (BOTH SIDES OF TUBE) AFTER FINISH (20 PLACES).

SHOP COPY

RETURN TO

ENGINEERING

UNCONTROLLED COPY
SUBJECT TO AMENDMENT
WITHOUT NOTICE

NO. 27397

